



Specifications

Operating Temperature Range	-40 to 105 °C (-40 to 221 °F)
Wiring Connections	Pig Tail (2 or 3 wire)
Enclosure	Metal 1/2 LBA or 4"x4"x2" PVC box
Sensor Types	100 Ω, 1K PT, 1K Nickel RTD's, 1801 Ω, 3K, 10K (type 2 & 3), 20K & 100K Thermistors, IC Sensors

Outside Air Temperature Sensor

Designed specifically for outside air temperature measurement, this single-unit device comes in a weather-proof gasketed enclosure (metal LBA for sensor only or ABS for transmitter units) with a sun and wind shield to protect it from false readings.

Installation

For best results locate the sensor on the north side of the structure high under an eave to prevent incorrect readings from direct sunlight and damage due to the elements. Mount the OSA enclosure with the sensor module facing down to prevent the accumulation of dirt or water.


The ABS enclosure is designed to be weatherproof with the use of the included enclosure screws and by using watertight conduit fittings for the wiring. These must be used or the warranty will be void.

Typical Wire Resistance Values

When using low resistance sensors (i.e. 100 ohm RTD), long wire runs can add significant error to the readings. Use the following chart to determine errors due to wire resistance or consider using a 1000 ohm sensor or a transmitter for better accuracy. Locate the type of wire being used. Multiply the total length of the wire (distance from the controller to the sensor and back) by the number found in the following chart for total resistance.

GAUGE WIRE TYPE	18 AWG	22 AWG	24 AWG
STRANDED (OHMS/FOOT)	5.85 mΩ	14.75 mΩ	23.29 mΩ
SOLID (OHMS/FOOT)	6.4 mΩ	15.85 mΩ	25.72 mΩ

Example Placement



Wiring & Color codes

All two-wire sensors are polarity insensitive. The three-wire sensors have the following color code:

Connection	OSA Wire Color
EXCitation	RED
SENse	RED
NEGative	WHITE

To connect a three-wire sensor as a two-wire, tie the EXCitation and SENse lines together. All connections should be made using either butt-splices or soldering. The use of wire nuts is not recommended.

IN-GE-TE51XFXXX-01-01 09/2012

Specifications

Power Supply 24 Vdc \pm 20% or 24 Vac \pm 10%

Consumption 22 mA maximum

Output Signals 4-20 mA or 0-5 Vdc or 0-10 Vdc Output Drive 400 ohm max for current output

5K ohm min for voltage output

Accuracy \pm 0.1% FSO

Operating Range . . . 0-50 °C (32-122 °F), 5-95 %RH Wire Connections . . . Screw terminal block (14-22 AWG)

Sensor 1000 ohm RTD

LCD Display 3 digit for 88.8 or 888 as necessary

0.95"w x 0.45" h (24 x 11 mm)

Enclosure 5.7"w x 3.95"h x 2.5"d (145 x 100 x 63 mm)

Wiring

Use shielded twisted pair wiring of at least 22 AWG for all connections and do not run the signal or power wires in the same conduit with wiring used to supply inductive loads such as motors. Disconnect the power supply before making any connections to prevent electrical shock or equipment damage. Make all connections in accordance with national and local electrical codes.

The transmitter is available with either 4-20 mA, 0-5 Vdc or 0-10 Vdc output signals. Follow the example wiring diagrams to determine the correct wiring for the product. All models have the same terminal functions. For 4-20 mA loop powered operation, only **POWER** and **OUTPUT** are required. The **COMMON** terminal is only used for voltage output types or for AC power.


Ensure the controller Analog Input (AI) matches the transmitter output signal type before power is applied. The device is reverse voltage protected and will not operate if connected backwards. The voltage output signal has a minimum load that it is able to drive and the current signal has a maximum load. Follow the ratings in the Specification section or inaccurate readings may result.

If the transmitter has a dual sensor probe, connect the RTD (Red/Black) leads to the SENSOR terminals. The second sensor is Green/White.


Operation

The product should be allowed to warm-up for several minutes before attempting to verify accuracy. Allow the transmitter to operate for 20 minutes before any calibration is performed.


Loop Powered Connection With Controller 24 Vdc Power



4-20 mA Connection With 24 Vac Power



0-10 Vdc Connection With Controller 24 Vdc Power



Operation can be verified by measuring the output signal. For voltage output models, measure the voltage between the **OUTPUT** and **COMMON** terminals. The voltmeter should read between 0-5 or 0-10 Vdc depending on the model. For current output models, insert a mA meter in series with the **OUTPUT** terminal and it should read between 4 and 20 mA. The LCD will indicate the same temperature value as the output signal.

Calibration

The unit can be calibrated in the field using precision resistance values equal to the zero and span of the temperature range. Simply replace the attached probe with the resistor, then adjust the ZERO and SPAN pots accordingly to obtain the correct output signal and display value. Repeat the adjustments until both values are correct.

IN-GE-TE51XFXXX-01-01 09/2012